

# Dynamic Power Factor Controller BR6000-T...



## Manual Version 4.0 E

# CONTENTS

Section 1	General / type series and accessories	2
Section 2	Installation of the controller / connection diagram	4
	2.1 Current measurement	5
	2.2 Programming of phase-correction	
	2.3 Alarm output / error messages	6
Section 3	Operating modes	6
Section 4	Automatic operation / display functions	7
Section 5	Programming	
	5.1 Program menu	8
	5.2 Programming lock	11
Section 6	Manual operation / Programming of fixed stages	12
Section 7	Service menu	13
Section 8	Expert mode	13
	8.1 Expert mode 1	
	8.2 Expert mode 2	14
Section 9	Control principle	15
Section 10	Interface	16
Section 11	Initial operation	16
Section 12	Maintenance and warranty	16
Section 13	Troubleshooting	17
Section 14	Technical data	18
Annex:	Annex 1 Table of control series	19
	Description of control-series editor	
	Annex 2 Default settings	20
	Annex 3 Controller coupling	21
	Annex 4 Application MMI6000	22
	Annex 5 MODBUS protocol	23
	Annex 6 Operating diagram (fast programming)	25

## **Section1 General**

The dynamic power factor controller BR6000-T.. represents the consequent development of the BR6000-series with new innovative ideas and a multitude of functions. It has been especially designed to control thyristor modules for dynamic switching of power capacitors for power factor correction (for example TSM-LC or similar). By using a very fast type of processor, it has been possible to obtain extreme short switching cycles which allows the usage for dynamic power factor correction.

In addition to a switching time of <20 ms, the intelligent control principle provides an extremely fast tuning of the power factor by simultaneous switching of several steps. Several parameters that can be edited allow an optimized adjustment to different thyristor modules.

The BR 6000-T.. is distinguished by user-friendly operation based on menu-guided displays in plain text. Its new features permit an intuitive mode of operation. Easy-to-understand symbols and texts in 8 local languages combine simplest operability with self-evident displays.

Main features:

- ☑ Six or 12 switching outputs (depending on the type)
- ☑ 20 pre-programmed control series with a self-optimized intelligent control response
- ☑ Control-series editor for user-defined control series
- ☑ Complete menu-guided operation and display
- ☑ Illuminated graphic display with 2 x 16 characters
- ☑ Four-quadrant operation
- ☑ Display of various line parameters (V, I, F, Q, P, S...)
- ☑ Display and monitoring of temperature
- ☑ Monitoring of capacitor power values with accessory MMI6000
- ☑ Storage of maximum line-parameter
- ☑ Manual / automatic operation
- ☑ Programming of fixed stages and the option of skipping individual outputs
- ☑ No-voltage turn-off
- ☑ Error detection for various states and interference-message output
- ☑ Complete 2nd parameter set programmable / switchable
- ☑ Switchboard-integrated housing 144x144x55 mm

### **Type series and accessories**

BR6000-T6	6 transistor outputs, 1 alarm relay
BR6000-T12	12 transistor outputs, 1 alarm relay, 1 additional user programmable message relay, input for second parameter set
BR6000-T12/S	with an additional interface RS232 or RS485
Accessories	- Meas. voltage adapter for grids without "N" or voltages above 300V - MMI6000 - MultiMeasuringInterface (for measurement of inherent current of capacitor bank ) - Remote display "FA6000"

The controller is supplied as standard for an operating voltage of 230 VAC (L-N), a measuring voltage of 30...300 VAC (L-N) 50/60 Hz and a measuring current of 5A or 1A (programmable). A voltage converter is required for different operating voltages.



**Caution!**

**Voltages which exceed the allowed voltage range can damage the device!**



Fig. 1 BR6000 front view

Operating mode

- Automatic
- Programming
- Manual operation
- Service
- Expert mode



Enter / OK  
Confirm and store values




Increase selected parameter



Reduce selected parameter



Fig. 2 BR6000 rear view



## Section 2 Installation and connection of the controller

The BR6000 is designed to be incorporated into the front panel of a PFC-cabinet. It requires a switchboard section of 138 x 138 mm to DIN 43700/ IEC 61554. The controller is inserted from the front and is attached by means of the appended clamps. The controller may be inserted only by qualified technicians and must be operated in accordance with the specified safety regulations.


Before the BR6000 is connected up, all leads and cables must be checked to ensure that no current is flowing through them and the current converter must be short-circuited. Care should be taken to ensure that the measuring voltage and current are in the correct phase position. The measuring-current circuit must be wired with copper leads of 2.5mm<sup>2</sup>. The connection should be set up as shown in Fig. 3. The specified safety regulations must be observed.

The measuring voltage may lie in the range from 30 - 300 V and is connected between L1-N (corresponds to 50 - 525 V L-L ). A connection between L-L is possible if a measuring-voltage converter is used and the corresponding phase shift U-I is programmed (see Programming).

For higher measuring voltages, a measuring voltage adapter is available as an accessory.

The operating voltage is 230 V +/- 10% and can be connected between L1 - N in a 400-V grid.

Fig. 3: BR6000 Connection plan



## 2.1 Current measurement

When installing the current converter, care should be taken to ensure that the load current flows through it. The outputs of the compensation network must be installed behind the current converter (in the direction of current flow). If the BR6000 is connected up via sum-current converters, the overall conversion ratio is entered.



**Caution !**  
**Current converter clamps should be grounded on one side !**


Example:

C.converter 1: 1000/5A

C.converter 2: 1000/5A

Sum-current converter: 5A+5A/5A

C.converter ratio is: 2000/5A



## 2.2 Programming of phase-correction


Adjustment of phase-correction between voltage and current in the meas. system is done in expert mode 1 (page 13)

Example:

Meas.current: L1

Meas. Voltage L3-L2

(V-converter must be used)



using	meas. current	meas. voltage	volt.transformer	phase-angle
standard	L1	L1 - N	no	0°
	L1	L1 - L2	necessary	30°
	L1 (k<->l)	L2 - N	no	60°
	L1	L3 - L2	necessary	90°
	L1	L3 - N	no	120°
	L1	L3 - L1	necessary	150°
	L1 (k<->l)	L1 - N	no	180°
	L1 (k<->l)	L1 - L2	necessary	210°
	L1	L2 - N	no	240°
	L1	L2 - L3	necessary	270°
	L1 (k<->l)	L3 - N	no	300°
	L1 (k<->l)	L3 - L1	necessary	330°

### 2.3 Alarm output / error messages

The alarm contact is closed in normal operation and opens in the event of a fault. The relevant fault is simultaneously shown on the display in plain text (alternating with the standard display in automatic operation). The following fault messages are displayed:


UNDER-COMPENSATED	Display and relay output
OVER-COMPENSATED	Display and relay output
OVERCURRENT	Display and relay output
MEASURING VOLTAGE ?	Display and relay output
OVERTEMPERATURE	Display and relay output
OVERVOLTAGE	Display and relay output
UNDERVOLTAGE	Display and relay output

Additionally several messages for different operation states are generated. An individual adjustment resp. suppression of particular messages is possible in expert mode 2. During suppression, the indication of the message in the display, a possible release via alarm-relays and effects on the controlling process will be prevented.

### Section 3 Operating modes

When the operating voltage is switched on, the BR6000 briefly displays its designation and software version, then changes to its normal operating status (automatic operation). The active cos-phi value is always displayed in the upper line and the currently connected capacitors are shown as symbols in the lower line (operating display).


Automatic operation



- ▶ The control direction is symbolized by a closed arrow
- ▶ Connecting-in
- ◀ Connecting-out
- ▶ The connecting-in arrow is always located after the maximum possible number of stages (end stop)
- An open arrow indicates that the required blocking time (discharge time) is running before an impending switching step
- ▶▶ A double arrow symbolizes fast switching of several branches

Control direction (here connected-in)      Supply display (for 4-quadrant operation)

Repeated pressing of the "Operating Mode" key takes the user to the various menus in sequence: **Automatic operation** - **Programming** - **Manual** (manual operation)- **Service** - **Expert** mode and back.



## Section 4 Automatic operation - display of network parameter

The BR6000 is set to automatic operation as standard. Capacitor stages are then automatically connected in or out in order to reach the target power factor. This happens when the required reactive power exceeds the value of the smallest capacitor stage.

In automatic operation, various network parameters can be displayed by repeatedly pressing the "ENTER" key:




Action	Display
ENTER	1 LINE VOLTAGE in V
ENTER	2 APPARENT CURRENT in A / %
ENTER	3 REACTIVE POWER in kvar / %
ENTER	4 ACTIVE POWER in kW / %
ENTER	5 APPARENT POWER in kVA / %
ENTER	6 DIFF. kVAR TO TARGET COS
ENTER	7 FREQUENCY in Hz
ENTER	8 TEMPERATURE in °C / °F
ENTER	Software version
ENTER	Return to: 1

The power value specifies the total power (3-phase) assuming symmetrical load. If no key is pressed for 60 seconds, the display automatically returns to the operating status!

### Switching outputs

The switching outputs of the BR6000T are executed as transistor outputs.

The transistor outputs are used via an additional auxiliary voltage (10 - 24 VDC) for a direct triggering of thyristor switches for the dynamic power factor correction (i.e. TSM).



**WARNING: Mixing-up of outputs and thus applying of 230 VAC on the transistor outputs will destroy the internal transistors !**



## **Section 5 Programming**

Pressing the "Operating mode" key once takes the user from automatic operation to **Programming mode**.

The upper display always shows the parameter and the lower one the set value. The values are changed by pressing the  $\uparrow$  /  $\downarrow$  keys. Subsequent pressing of the "ENTER" key stores the value and takes the user to the next parameter.

To quit programming mode in any step, press the "Operating mode" key.

### **5.1. Program Menu**

**LANGUAGE SELECTION:** This selects the language of the operating menu  
(German, English, Spanish, French, Russian, Czech, Dutch, Polish)

**1 I-CONVERTER PRIM:** [ 5...13000]A

This selects the primary current of the current converter. Adjustment is via the  $\uparrow$  /  $\downarrow$  keys. Save and continue with ENTER

**2 I-CONVERTER SEC:** [ 5 or 1]A

This sets the secondary current of the current converter  
Selection via  $\uparrow$  /  $\downarrow$ . Save and continue with ENTER

**3 END STOPP:** [ 1...6 or 1...12 ]

By setting the end stopp, the number of active capacitor branches is matched to the respective capacitor bank. This is done via the  $\uparrow$  /  $\downarrow$  keys. The visible symbols of the capacitors correspond to the connected outputs. The maximum possible number of capacitor branches is pre-set at the works (BR6000-T12:12 branches).

Save and continue with ENTER

**4 CONTROL SERIES:** [ 1...20 + E ]

The ratio of the capacitor branch power determines the control series, the power of the first capacitor always being assigned the value 1. The control series required for the compensation network is again selected via the  $\uparrow$ / $\downarrow$  keys. If the required control series should exceptionally not be present (Annex 1), the user may define a special one (control series "E"). More on this point in the control-series editor in Annex 1.

Save and continue with ENTER

**5 CONTROL PRINCIPLE:** The control preference may be selected here:

**SEQUENTIAL connection**

**LOOP connection**

**INTELLIGENT loop connection** (default setting)

**COMBINED CHOKE**

See Section 9 for an explanation of the various control modes.

Selection with  $\uparrow$  /  $\downarrow$  keys. Save and continue with ENTER

**6 POWER 1. STAGE:** [ 0.01 ... 255.99 ] kvar

To determine the controller's response sensitivity, the dimensions of the network's smallest capacitor (stage 1) must be known. They are entered in two steps in kvar. The integral kvar values (before the comma) are initially selected via the  $\uparrow$  /  $\downarrow$  keys and saved with ENTER. The positions after the comma are then selected, again via the  $\uparrow$  /  $\downarrow$  keys. If the response sensitivity of the BR6000 is being undercut, a warning will occur ( indication of "!" in the display )  
Save and continue with ENTER

**7 TARGET COS PHI:** [ 0.8 ind ... 0.8 cap ]

By setting the target cos phi, the power factor to be attained via the PF correction is defined. It is also set via the  $\uparrow$  /  $\downarrow$  keys.  
Save and continue with ENTER

**8 MEASURING VOLTAGE** [ 30 ... 305]V


Programming the measuring voltage (L-N) of the system (direct measurement) or the L-N voltage on the primary side of a measuring-voltage converter. The values programmed here always refer to the voltage L-N in the system! The voltage is selected via the  $\uparrow$ / $\downarrow$  keys. Save and continue with ENTER.

**9 V - CONVERTER RATIO** [ NO / 1.1 ... 990 ]

When a measuring-voltage converter (e.g. for HV- measurement) is used, its conversion ratio should be programmed here.

Example: Voltage converter 20000V:100 V => Conversion ratio: 200

Selection via the  $\uparrow$ / $\downarrow$  keys. Save and continue with ENTER.



**10 CONNECTING TIME** [ 20ms ... 1 sec.]

This refers to the time between connecting the capacitors to increase the momentary network capacitance. It should be noted that in practical operation the real connection time is affected by the discharge time (locking time).

Default setting: 1 sec.

Selection is performed via the  $\uparrow$ / $\downarrow$  keys. Continue with ENTER

## 11 DISCONNECTING TIME [ 20ms ... 1 sec.]

This refers to the time between disconnecting the capacitors to reduce the momentary network capacitance..

Default setting: 1 sec.

Selection is performed via the  $\uparrow$  /  $\downarrow$  keys. Continue with ENTER

## 12 DISCHARGE TIME [ 20ms ... 2 sec.]

This is the time for which an individual output is blocked between connecting and disconnecting. This blocking time has priority over connecting and disconnecting times. It depends on the capacitor discharge rating and thus is specified by the compensation network.

Default setting: 200 ms

Selection is performed via the  $\uparrow$  /  $\downarrow$  keys. Continue with ENTER

## 13 ALARM TEMP [ 50...85]°C

The alarm temperature programmed here is the temperature at which the capacitor stages are disconnected in steps. The controller's **alarm relay** responds after 60 seconds. At the same time the display shows the cause of the alarm (over-temperature). If the temperature drops again, the required branches are automatically re-connected in steps.

The selection is performed with the  $\uparrow$  /  $\downarrow$  keys. Save and continue with ENTER.

## 14 MESSAGE RELAY ( available only at version -12 and -12/S )

The message relay can be programmed for one of the following options as required:

"Fan": Relay switches the external cabinet fan.  
(Default) The switching threshold can be programmed under point 15.  
Display: "**F**"

"Supply": Message when active power is supplied. Display: "**S**"

"Undercurrent": This message appears whenever the measuring current is not reached. Display: "**U**" The signal is generated when the value drops below the response sensitivity of the controller.

"Remote control R1": Coupling of two controllers via remote control input,  
R1= Controller is configured as controller 1 (master)

"Remote control R2": Coupling of two controllers via remote control input,  
R2= Controller is configured as controller 2 (slave).  
A description for the coupling of two controllers can be found in the annex 3. When this function is selected, the input cannot be used for the signal '2nd parameter set' and the output cannot be used for the fan.

Selection is via the  $\uparrow$  /  $\downarrow$  keys. Save and continue with ENTER.

## 15 FAN TEMP\* [15...70]°C

Input of the switching threshold for the fan. Only active if option 'Fan' is selected

## 16 Programming of 2nd parameter set\*[NO] (YES / NO)

\* only applicable for controller types -12 or -12/S



\* only active if message relay is programmed as "FAN", "SUPPLY" or "UNDERCURRENT"

As a standard, the values of the 2 parameter set are equal to the values of the normal parameters. By changing particular parameters, for example the cos-phi can be switched. Other possible applications may be switching of current transformer or switching of switching times.

By triggering of a 230 V-signal at the external input, the 2nd parameter set will be activated with the following values:

17. I-converter prim, 18. I-converter sec. 19. End stopp, 20. Control series,  
21. Control principle, 22. Power 1.stage, 23. Target cos-phi, 24. Switch-on time,  
25. Switch-off time, 26. Discharge time

The values of the 2nd parameter set and the indication of activation is marked with the following symbol in the display.



## 27 DELAY-TIME OF ERROR-MESSAGES [0... 240] sec.

The delay time for error-messages in the display can be changed here.

Default: 20 sec.

## CONTRAST [7] (5...10)

The display contrast can be changed with this menu point. The contrast depends to a certain degree on the viewpoint of the observer, i.e. on the insertion height of the equipment in the switching cabinet. The ↑/↓ keys can be used to set an optimal contrast.

## BASIC SETTING: [NO] (YES / NO)

When the selection is made with YES and confirmed with ENTER, all parameters are reset to the basic setting made by the PFC-system manufacturer.

(Optimal network values when the controller was supplied with a complete PFC-system). If the controller is supplied from the works, this point corresponds to the default setting. **CAUTION: All user settings are lost!**

Programming is now completed. The controller has returned to point 1 of the programming menu.


## 5.2 Programming lock

The BR6000 is equipped with a programming lock to ensure protection from unauthorized or inadvertent changes to the system parameters. The lock can be activated in expert mode. If the lock is active, all parameters can be checked but not changed.

## **Section 6      Manual operation (initial operation, maintenance, service) Programming of fixed stages**


In manual operation, capacitor branches can be connected/disconnected **in the set control series and switching time** - irrespective of prevailing power-line conditions. The starting condition is STOPP (no stages connected). Connections are made by pressing the **↑** key. Pressing **↓** initially leads back to STOPP mode. Repeated pressing of **↓** leads to the disconnection of stages. The active operating status and active power factor are always shown on the display (self-explanatory).

Manual operation



Pressing ENTER takes the user to the menu point "Programming of fixed stages". In the normal case, all stages are programmed for automatic operation (default setting).

Setting of fixed stages



AUTO OFF FIX (Currently selected stage blinks)

In special cases, all controller outputs (C1 - C12) may be permanently defined in succession (continued switching via ENTER) for the following statuses:

**OFF:** The output is continuously disconnected - e.g. for temporarily disconnecting a defective capacitor. The capacitor symbol for this output is faded out. Underlining appears.

**AUTO:** Automatic (normal) operation

The relevant output is marked by a capacitor symbol.

**FIXED:** The output is continuously connected, e.g. for fixed PFC. The output is marked by an underlined capacitor symbol.

**TEST:** short-term switch-on of individual outputs possible for test purpose

The active stage is blinking. The required status is set via **↑/↓**. By pressing ENTER, the user saves this step and moves to the next stage.

The programmed statuses for the outputs also remain visible on the display in automatic operation.

After the required settings have been made, pressing the "Operating Mode" key takes the user to the next menu ("Service") or further to "Automatic Operation".

## **Section 7 Service menu**

The service menu is reached by the operating-mode key.

The stored maximum values of the network parameters can be displayed here as well as the number of switching operations of the individual capacitors and their operating time. The desired stages [in square brackets] can be selected via the arrow keys.

In addition, a fault memory is available, in which the last 8 fault states of the system are stored with fault code and in plain text. (This allows, for example, capturing short lived events of overtemperature or overvoltage)

Action	Display
ENTER	1 max. VOLTAGE in V
ENTER	2 max. REACTIVE POWER in kvar / %
ENTER	3 max. ACTIVE POWER in kW / %
ENTER	4 max. APPARENT POWER in kVA / %
ENTER	5 max. TEMPERATURE in °C / °F
ENTER	6 RESET the maximum values
ENTER	ERROR MEMORY E [1] - .... in plaintext
ENTER	ERROR MEMORY RESET
ENTER	Back to 1

## **Section 8 Expert mode 1 and 2**

The expert mode is meant for the adjustment of values which normally should not be changed. As a protection against mal-operation this level has an access code branching out in Expert mode 1 or 2.

Password: Expert mode 1: "6343" Expert mode 2: "2244"

### **8.1. Expert mode 1**

- 2 BASIC SETTING NEW** [NO] (available: NO/YES)  
Storage of active programming as a new basic setting (usually performed by the PFC-system manufacturer). Caution: The original values are overwritten in the process!
- 3 SWITCHING POWER max** [100] kvar (multiples of the smallest stage)  
This factor specifies the maximum power which may be switched in one switching step. It can be used to control the intelligent control system, which switches several stages as a function of the power-factor requirement.
- 4 SWITCH.TRIGGER** [66]% (30...100%)  
Threshold for switching on of next stage. It should not be changed in the normal case!
- 5 OPERATING LOCK** [NO] (NO / YES )

- 6 PHASE I** [0°] Adjustment of current phase position  
 [L1] - L1 - N
- 7 PHASE U** [0°] Adjustment of voltage phase position  
 L1 - [L1 - N]

Phase correction between voltage and current in the measuring system. This setting allows to measure also in systems without neutral. However, the measuring voltage may not exceed 300 V (if necessary, a voltage converter must be used).

- 8 OUTPUT 1. STEP** [0...255] (0...2550)  
 The range for entering the stage output can be increased to [0...2550] here, (e.g. for medium voltage measurement)

- 9 CONTROL [3] PHASE** (3 / 1)  
 The measuring system of the controller is generally based on single-phase measurement. For all standard settings (three-phase), the measurement is converted and all outputs displayed as three-phase values (symmetry in grid assumed). In the single-phase setting, display and control apply only to the single-phase value measured (application: single-phase correction in asymmetrical grids).

- 10 PROTOCOL** \*only with option .../S (interface)  
 [ MODBUS RTU ] MODBUS protocol for individual usage  
 [ OFF]  
 [ ASCII OUT ] output of grid-values as ASCII-file (s.page 16)

Depending on the protocol selection, the appropriate configuration-menu is offered:

- 11 BAUD RATE** [38400] (4800...38400) Transmission rate  
**12 Number of MMI** [ 1 ] (1 ... 9) Nos of connected MMI  
**13 ADDRESS** [ 1 ] (1 ... 32) Address  
**14 UPPER VALUE** [130]% (110 ...200%) Switch. threshold MMI  
**15 LOWER VALUE** [60]% (40 ... 90%) Switch. threshold MMI  
**16 TEST ATTEMPT** [10] (3 ... 255)  
**17 TEST-TIME** [10] (3 ... 255)  
**18 ASCII time** [10]sec. (1...255 sec) Repetition-time ASCII

**8.2. Expert mode 2** ( Password: 2244)

The additional 2nd expert mode includes all messages for operation, warning and error which are displayed by the BR6000. Here they may be deactivated separately. When deactivated, the indication of the message in the display as well as possible activation of the relay or effects on the control behavior are suppressed (detailed list of all messages in menu plan last page).

- EXPERT MODE 2** [YES] (YES/NO)

**Activation of particular operation, warning and error messages (s. above) (19 messages in total)**

- ALARM TIME** [60] sec. (1...255 sec.)  
 Time after which the alarm relay will respond

## **Section 9 Control principle**

The control response of the BR6000 can be selected in programming mode. In principle, the controller has four different control modes:

### **1. Sequential connection**

In sequential connection, the required capacitor stages are successively connected and disconnected in stages (last in - first out). The ranking of each step always corresponds to the power of the smallest stage.

**Advantage:** Exact definition of the next capacitor to be connected in each case

**Disadvantage:** Long settling time, high switching frequency of the small stages

**In order to shorten the settling time, the BR6000 switches several stages simultaneously for a large power-factor requirement. This applies to all control types. The maximum dimensions of the simultaneously switching branches can be changed in expert mode. If the value of the smallest stage is pre-selected, the conventional sequential connection is obtained.**

### **2. Loop connection**

In this variant, the controller operates in loop mode (first in - first out) which minimizes the wear on the capacitor bank, i.e. where stages are of equivalent dimensions, the stage which was disconnected for the longest period of time is always connected next.

**Advantage:** Balanced utilization of equivalent stages and thus an increased operating life of the capacitor bank.

**Disadvantage:** This mode can only be used in control series with groups of the same stage power and long settling time, as every switching step corresponds to the value of the smallest stage.

### **3. Intelligent loop connection (default setting)**

The intelligent control principle combines the advantages of the network-sparing loop connection (first in - first out) with a much faster settling time, even for large load skips, and reaches this goal with the fewest possible switching operations of the capacitor stages. The optimized time response is achieved by the simultaneous switching of several or larger capacitor groups as a function of the missing power factor in the power line. Both the number of real switching frequencies of the capacitors as well as the turn-on times of the branches are considered.

**Advantage:** Reaches the target cos phi in a fast-optimized settling time with a low switching frequency of the capacitors.

### **4. Combined de-tuning (special case for combined de-tuned banks)**

Within a combined de-tuned application, 2 adjoining equal steps are switched with just one joint choke. This pairwise de-tuning requires an appropriate closed control series (i.e. 1:1:1:1..., 1:1:2:2..., 1:1:2:2:4:4... or similar)

The condition for the switching behavior is defined in such a way that the number of activated odd steps is always greater than or equal to the number of activated even steps. The controller complies with the requirements of the control regime while largely conforming to the intelligent switching behavior.



## **Section 10 Interface \*(option)**

The BR6000-T is equipped with an RS 232 or RS 485 interface as an option. It can be used to implement the following functions:

- ☑ Connection of a remote display (system accessories) for clear read-out of all measurements on large seven-segment triple displays
- ☑ Selection of MODBUS (see Annex 5) or ASCII (see table below) for permanent display of grid parameters in ASCII format). Any ASCII editor can be used.

NEW: Using with MMI6000 e.g. for measurement of inherent current of capacitor bank

The following data are permanently displayed and refreshed via ASCII (ASCII Protocol):

Voltage	e.g.	"230 V"	
Current	e.g.	" 85 A"	
Power factor	e.g.	"-0.98"	means: CAP
Reactive power	e.g.	"100 kvar"	
Active power	e.g.	"100 kW"	
Apparent power	e.g.	"100 kVA"	
Outputs	e.g.	"XXX-----"	means: 3 steps active

## **Section 11 Initial operation**

The controller must have been installed before being set up and operated.

All network-specific parameters are fully programmed as described in section 5 (Programming) by being entered in sequence and stored. The controller is then set to automatic operation with the operating mode key. It is now ready for operation.


## **Section 12 Maintenance and warranty**

The BR6000 should need no maintenance if the operating conditions are observed. However, it is recommended that a functional check of the controller be performed in conjunction with the regular checking of the capacitor bank. In the event of any interventions in the controller during the warranty period, all warranty claims lapse.

### Section 13 Troubleshooting

Fault	Check / Solution
<p>At target <math>\cos \phi = 1</math> and inductive load, switch-off or connection of capacitor in the corrected line Supply / Drawing mismatched Wrong line <math>\cos \phi</math> is displayed</p>	<p>Check terminals of the measuring voltage and current (I and k)! Check phase position</p>
<p>Display: "UNDER CURRENT"</p>	<p>See above</p>
<p>Display: "OVERCURRENT" Alarm relay: after 1 min.</p>	<p>Current in measuring range? Line interruption? Wrong current-converter factor? Current transformer short-circuited?</p>
<p>Display: "UNDERCOMPENSATED" Alarm relay: after 1 min.</p>	<p>Check current-converter ratio Go through measuring current range</p>
<p>Display: "OVERCOMPENSATED" Alarm relay: after 1 min.</p>	<p>Check connection and phase position! All stages connected - target <math>\cos \phi</math> not reached: compensation network sufficiently dimensioned?</p>
<p>Display: "MEASUREMENT VOLTAGE ???" Alarm relay: after 1 min.</p>	<p>Check connection and phase position! Capacitive grid, although all stages disconnected</p>
<p>Display: "OVERTEMPERATURE" Alarm relay: after 1 min.</p>	<p>No measurement voltage!</p>
<p>Stages are disconnected for an inductive line or connected for a capacitive line</p>	<p>Cabinet temperature too high: Outputs are switched off in stages irrespective of power-line conditions</p>
<p>The controller does not connect all stages, or <math>\cos \phi</math> does not change at the last stages In automatic operation, individual stages are not connected or disconnected</p>	<p>If a target <math>\cos \phi</math> is set which deviates from 1 despite an inductive line load, the display &lt; (disconnect stages) may light up. The arrows indicate the control direction and not the line conditions.</p>
<p>In strongly asymmetrically loaded lines, differences may occur between control response and power-factor measurement, as the power factor is measured in single phase.</p>	<p>Check END STOPP !</p>
<p>No operating voltage</p>	<p>Check whether individual stages are programmed as fixed stages or OFF in the "Manual operation / Fixed stages" menu! Line measurements allow the most favorable phase for measuring the power factor to be determined. The current converter is set accordingly for the measuring current.</p>
	<p>Note: No display, alarm relay is activated (open)</p>

## Section 14 Technical data

Type series	BR6000-T ....
Outputs	6 or 12
Languages	G / E / ES / RU / NL / CZ / PL / F
Switching power of outputs	24 VDC, appr. 20mA für triggering TSM-LC
Number of active outputs	Programmable
Operation and display	Illuminated graphic display 2 x 16 characters with convenient operating level
Number of control series	20
User-defined control series	1
Control principle	Sequential connection, loop connection or self-optimized switching response Four-quadrant operation
Operating voltage	230 VAC, 50 / 60Hz
Measuring voltage	30...300 VAC (L-N), 50 / 60Hz
Measuring current	X : 5 / 1A selectable
Power drawn	< 5 VA
Sensitivity	50 mA / 10 mA
Target cos phi	0.8 inductive to 0.8 capacitive adjustable
Connecting time	Selectable from 20 ms - 1 sec.
Disconnecting time	Selectable from 20 ms - 1 sec.
Discharge time	Selectable from 20 ms - 1 sec.
Fixed stages/ skipped stages	Programmable
Alarm relay	Standard
No-voltage triggering	Standard
Display of power-line parameters	Power factor, voltage, apparent current, frequency, reactive-, active-, apparent power, missing kvar, temperature
Storage of maximum values	Voltage, reactive power, active power, apparent power, temperature
Temperature measurement range	0 - 100°C
Error memory	Last 8 error states are stored
2nd parameter set 	Available at version -T12 und -T12/S
Accuracy	Current, voltage: 1% Reactive-, active-, apparent power: 2%
Housing	Switchboard-integrated housing DIN 43 700, 144 x 144 x 53 mm
Weight	1 kg
Operating ambient temperature	-10 to +60°C
Protection type to DIN 40 050	Front: IP 54, Rear: IP 20
Safety guidelines	IEC 61010-1:2001, EN 61010-1:2001
Sensitivity to interference (industrial areas)	EN 50082-1:1995 IEC 61000-4-2: 8kV IEC 61000-4-4: 4kV
Option /S 232 (485)	Additional interface RS232 or RS485

**Annex 1: Table of control series**

No.	Control series	Loop connection
1	1 : 1 : 1 : 1 : 1 : 1 : 1 : 1 : 1 : 1 : 1 : 1 : 1	Possible
2	1 : 2 : 2 : 2 : 2 : 2 : 2 : 2 : 2 : 2 : 2 : 2 : 2	Possible
3	1 : 2 : 3 : 3 : 3 : 3 : 3 : 3 : 3 : 3 : 3 : 3 : 3	Possible
4	1 : 2 : 3 : 4 : 4 : 4 : 4 : 4 : 4 : 4 : 4 : 4 : 4	Possible
5	1 : 2 : 4 : 4 : 4 : 4 : 4 : 4 : 4 : 4 : 4 : 4 : 4	Possible
6	1 : 2 : 3 : 6 : 6 : 6 : 6 : 6 : 6 : 6 : 6 : 6 : 6	Possible
7	1 : 2 : 4 : 8 : 8 : 8 : 8 : 8 : 8 : 8 : 8 : 8 : 8	Possible
8	1 : 1 : 1 : 1 : 2 : 2 : 2 : 2 : 2 : 2 : 2 : 2 : 2	Possible
9	1 : 1 : 1 : 1 : 1 : 6 : 6 : 6 : 6 : 6 : 6 : 6 : 6	Possible
10	1 : 1 : 2 : 2 : 2 : 2 : 2 : 2 : 2 : 2 : 2 : 2 : 2	Possible
11	1 : 1 : 2 : 2 : 2 : 4 : 4 : 4 : 4 : 4 : 4 : 4 : 4	Possible
12	1 : 1 : 2 : 2 : 4 : 4 : 4 : 4 : 4 : 4 : 4 : 4 : 4	Possible
13	1 : 1 : 1 : 2 : 2 : 2 : 2 : 2 : 2 : 2 : 2 : 2 : 2	Possible
14	1 : 1 : 2 : 3 : 3 : 3 : 3 : 3 : 3 : 3 : 3 : 3 : 3	Possible
15	1 : 1 : 2 : 4 : 4 : 4 : 4 : 4 : 4 : 4 : 4 : 4 : 4	Possible
16	1 : 1 : 2 : 4 : 8 : 8 : 8 : 8 : 8 : 8 : 8 : 8 : 8	Possible
17	1 : 2 : 2 : 3 : 3 : 3 : 3 : 3 : 3 : 3 : 3 : 3 : 3	Possible
18	1 : 2 : 3 : 4 : 4 : 8 : 8 : 8 : 8 : 8 : 8 : 8 : 8	Possible
19	1 : 2 : 2 : 4 : 4 : 4 : 4 : 4 : 4 : 4 : 4 : 4 : 4	Possible
20	1 : 2 : 2 : 2 : 4 : 4 : 4 : 4 : 4 : 4 : 4 : 4 : 4	Possible
"E"	Control-series editor	Possible

**Control-series editor (programming up to a rating of 30)**

The control-series editor allows the user to simply define his/her own control series if the required control series is not available for any reason. The last control series - Control Series E - is selected by pressing the "Programming" key (point 4: Control series) and confirmed with ENTER. This leads to the insertion of an additional menu point in the main menu -> the control-series editor. It may be reached via the "Operating Mode" key.




In the control-series editor, all stages can be set in succession to the desired value with the selection keys ↑ / ↓. The next stage in each case is reached by pressing ENTER. In the control series editor, the various steps may be programmed up to a rating of 30 (!). The rating >9 is indicated in the display as follows: 10=A, 11=B, 12=C, 13=D, 14=E, 15=F, 16=G .... 30=U

**NEW: ALL** control series can be generated (even downwards). The customer will decide whether the generated control series is of sense.

The maximum number of stages can be limited by a programmed END STOPP < 12.

## **Annex 2: Default settings**

Note: The following values for the default settings apply only if the controller is supplied directly from the manufacturer. Otherwise, these values may have been replaced by settings made by the manufacturer of the compensation network (optimal values for the relevant network).

No.	Parameter (* as option)	Default setting	Programmed values of this system (to be entered by manufacturer or operator)	
0	LANGUAGE	ENGLISH		
1	I CONVERTER prim.	1000 A		
2	I CONVERTER sec.	5 A		
3	END STOPP	12 ( 6 )		
4	CONTROL SERIES	1		
5	CONTROL PRINCIPLE	INTELLIGENT		
6	POWER 1. STAGE	25.00 kvar		
7	TARGET COS-PHI	0.98 IND		
8	MEASURING VOLTAGE	230 V L-N		
9	V- CONVERTER RATIO	- NO -		
10	SWITCH- IN TIME	1 sec.		
11	SWITCH- OFF TIME	1 sec.		
12	DISCHARGE TIME	0.2 sec.		
13	ALARM TEMP.	55 °C		
14	MESSAGE RELAY *	FAN		
15	TEMP. FAN ON *	30 °C		
27	DELAY ERROR MESSAGE	20 sec.		
	2nd parameter set *		Default values are the same as in the 1. parameter set	
	Capacitor stages	AUTO		
	Password Expert mode 1	6343	Cannot be changed	
	Password Expert mode 2	2244	Cannot be changed	
	Trigger value	66%		
	Max.simult.switch.power	4 x smallest stage		
	Operating lock	- NO -		
	Phase shift U/I	0 °		
	Power 1. stage	0...255 kvar		
	Control	3 - phase		
	Protocol*	MODBUS-RTU		
	Baudrate*	38400		
	Address*	1		
	Numbers of MMI6000*	1		
	ASCII delivery time*	10 sec.		


**Annex 3: Controller coupling** (Programming under "14 message relay")

For example, coupling is useful when two separate installations are operating on two transformer supplies and a coupling exists for both systems. When the coupling is closed (because only one supply is working), it is still possible to access the total compensation power of both installations via the coupling of the controllers. The network is then operating in master-slave mode. When all stages of the first controller are connected, the second controller is taking over and switches the remaining stages.

It is therefore also possible to extend networks easily.


When coupling is requested, it is necessary to program "controller1" (as master) and "controller2" (as slave) in this menu point.

For coupling, the controllers of the two installations have to be connected as follows:



When the coupling switch is open, both installations are operating independently. When the coupling is closed, master-slave operation is initiated automatically. It is an advantage of this simple solution that an additional serial interface is not required.

**NOTE:** By coupling a BR6000 with a dynamic controller (BR6000-T), a mixed dynamic system can be designed that implements economically the advantages of a dynamic fast network. (Fast changing loads are compensated dynamically and basic loads and slowly changing loads are compensated conventionally):



## Annex 4: Capacitor current monitoring using MMI6000

### Application

For permanent current monitoring inside the compensation system the MMI6000 is recommended as an accessory for the BR6000. This measuring device is able to determine the sum current of the complete PFC system as well as the current of single capacitor branches.

By monitoring the current of the installed capacitors, extraordinary grid conditions (e.g. harmonic currents which may cause an overload of capacitors) can be identified. In such a case, the power factor controller switches off the relevant compensation stages as long as the extraordinary situation continues. Monitoring of the capacitor current also means monitoring of the capacitor condition (damages, aging ...) and thus gives the opportunity to avoid consequential damages.

The MMI6000 will improve the reliability and safety of a PFC-system.

### Method of operation:

The MMI6000 measures the sum current inside the PFC system. For this a current transformer has to be installed at the power input of the compensation system. During each switching operation, the actual current change is measured and compared to the rated current of the switched capacitor(s). In between the switching operations the current of the complete system is monitored.

If the measured current of a step is too low (default 60%), this step is switched off. The relay is deactivated and the BR6000 display shows "E" (error) for this step. The alarm relay is activated. A reactivation of the step is possible in manual mode.

In case the current of a step is too high (default 130%), this step is also switched off. The BR6000 display shows an inverted capacitor symbol. The current is further on checked periodically. If the rated current reached again, the step is reactivated.

If the sum current of the complete PFC system too high (default 130%), stages are switched off one after another and alarm relay is set. Periodical measurements are performed to check whether the current reaches the nominal value again. If so, the step is reactivated.


### Settings MMI6000:

- Operation mode: Coupling MMI-BR6000-T
- Grid: 3-phase (DS)
- Baudrate: 38400

### Settings BR6000: (ExpertMode)

- Protocol: Master-MMI
- Baud rate: 38400
- Number of MMI connected
- Upper limit (%), lower limit (%)  
(limits of the capacitor / system output)

### Principle circuit diagram:



### CAUTION:

- For the bus-connection a shielded cable has to be used!
- Bus-connections (in and out) have always to be made directly to the relevant device!
- The terminating resistors inside the connected devices have to be activated (DIP-switch ON).
- Smallest switching time in this mode is 80 ms !

**Annex 5: MODBUS-Protocol - Part 1: -only read-register ( Functioncode 3 )**

F	Modbus No	Register / Function	Range	unit / digit	
3	0	Reactive power H-Part	32 Bit Long	1 var	
	1	Reactive power L-Part			
	2	Active power H-Part			
	3	Active power L-Part	32 Bit Long	1 W	
	4	Apparent power H-Part			
	5	Apparent power L-Part			
	6	Diff. Reactive power H-Part	32 Bit Long	1 var	
	7	Diff. Reactive power L-Part			
	8	Actual system output ( in var )			
	9		32 Bit Long	1 var	
	10	Actual system output ( in % )			
	11	Voltage resolution of 0.1V, max. 300V			16 Bit
	12	Current resolution of 0.1A	32 Bit Long	0.1 A	
	13				
	14	Voltage with resolution of 0.1V ( e.g. 2314 = 231,4V			
	15	Number of actual stages	16 Bit	1 stage	
	16				
	19	cos-Phi (100 = 1.00)			
	20	Line voltage	16 Bit	1 V	
	21	Apparent current	16 Bit	1 A	
	22	Frequency	16 Bit	1 Hz	
	23	Temperature (cabinet)	16 Bit	1 °C	
	24	Temperature (controller)	16 Bit	1 °C	
	25 - 29	Several state messages	16 Bit		
	30	Outputs (relays)	16 Bit		
	51	cos-Phi (100 = 1.00)	16 Bit	0.01 (- = cap)	
	60	Failure - register	16 Bit	Bit 0 - 7	
	61	Warnings - register	16 Bit	Bit 0 - 7	
	62	Messages - register	16 Bit	Bit 0 - 7	
	71 - 82	Status outputs 1...12	16 Bit	0 = OFF 1 = ON	
85 - 100	Register compressed values	16 Bit			
101	Language	0 - 7	1 = English		
102	I - converter prim.	0 - 255	0 = 5A ...		
103	I - converter sek.	6 - 7	6 = 1A ...		
104	End stopp	1 - 12			
105	Control series	1 - 21			
106	Control mode	12 - 15	12 = Sequ.		
107	Power 1st stage	0 - 255			
108	Power 1st stage	0 - 99			
109	Target cos Phi	80 - 120	80 = 0,8 cap.		
110	Meas. voltage	29 - 255	Volt		
111	Voltage converter ratio	1 - 126	Ratio		
112	Switching - ON time				
113	Switching - OFF time				
114	Discharge time				
115	Alarm temperature	50 - 85	°C		
116	Message relay	19 - 25	19 = external		
117	Fan temperature	15 - 70	°C		
118	2. parameter set	0 - 1	NO / YES		
119	I - converter prim.	0 - 255	0 = 5A		
120	I - converter sek.	0 - 1	0 = 1A		
121	End stopp	1 - 12			
122	Control series	1 - 21			
123	Control mode	0 - 4	0 = Sequ.		
124	Power 1st stage	0 - 255			
125	Power 1st stage	0 - 99			
126	Target cos Phi	80 - 120	80 = 0.8 cap.		
129	Switching - ON time				
130	Switching - OFF time				
131	Discharge time				
132	Delay Error display	1 - 255	sec.		



Part 2: - only-write -register ( Functioncode 6 )

	Modbus No.	Register / Function	Range	unit / digit		
6	1	Language	0 - 7	1 = English		
	2	I - converter primary	0 - 255	0 = 5A...		
	3	I - converter secondary	6 - 7	6 = 1A...		
	4	Endstopp	1 - 12			
	5	Control series	1 - 21			
	6	Control mode	12 - 15	12 = Sequ.		
	7	Power first stage	0 - 255			
	8	Power first stage	0 - 99			
	9	Target cos Phi	80 - 120	80 = 0.8 cap.		
	10	Meas. voltage	29 - 255	Volt		
	11	Voltage converter ratio	1 - 126	Ratio		
	12	Switching-ON time				
	13	Switching-OFF time				
	14	Discharge time				
	15	Alarm temperature	50 - 85	°C		
	16	Message relay	19 - 25	19 = external...		
	17	FAN temperature	15 - 70	°C		
	18	2. parameter set	2 0 - 1	NO/YES		
	19	I - converter prim.	2 0 - 255	0=5A		
	20	I - converter sek.	2 0 - 1	0=1A		
	21	End stopp	2 1 - 12			
	22	Control series	2 1 - 21			
	23	Control mode	2 0 - 4	0=Sequ.		
	24	Power 1st stage	2 0 - 255			
	25	Power 1st stage	2 0 - 99			
	26	Target cos Phi	2 80 - 120	80=0.8 cap		
	29	Switching - ON time	2			
	30	Switching - OFF time	2			
	31	Discharge time	2			
	32	Delay Error display		1 - 255	sec	
		40	Remote control Register value H = Data 1 ( switch.power max = multiples of the smallest stage )	8 Bit	1 - max	
		Register value L = Data 2 0 - Remote OFF 1 - Switching DOWN, 2 - Stopp 3 - Switching UP	8 Bit	0 - 3		

Part 3 example

MODBUS - Functioncode 3 (only-read-register) example meas. voltage					MODBUS - Functioncode 6 ( only-write-register ) example remote-control ( Remote-ON )				
answer					answer				
Byte 1:	Slave Adresse	1	Sl. Address	1	Slave Adresse	1	1		
Byte 2:	Functioncode	3	Funct. code	3	Functioncode	6	6		
Byte 3:	Reg.start address "H"	0	No of Bytes	2	Registeradr. "H"	0	0		
Byte 4:	Reg.start address "L"	20	Data H	0	Registeradr. "L"	40	40		
Byte 5:	Reg. number "H"	0	Data L	233	Reg.value H (Data1)	1*	1		
Byte 6:	Reg. number "L"	1	CRC L	121	Reg.value L (Data2)	3*	3		
Byte 7:	CRC testcode "L"	196	CRC H	202	CRC testcode "L"	72	72		
Byte 8:	CRC testcode "H"	14			CRC testcode "H"	83	83		

\* Reg.value 1 = switch-up with max. 1 step (1)  
\* Reg.value 3 = remote switching-up (3)


**NOTE:**


Due to the priority of the control function of the power factor controller before data exchange, please consider that per command 24 consecutive values maximum (s. table) are transferred blockwise.  
Also, parameters should not be retrieved more than 1 x /second.

Settings: 8 data bit, 1 stop bit, no parity

only available if control serie "E" is selected

AUTO MODE





Operating diagram (Brief programming)  
Power Factor Controller BR 6000-T (V4.0)

